

## Failsecure standard. Field adjustable from Failsecure to Failsafe as shown.





## **Electrical Data:**

Notes:

conductors larger than 18AWG

Dual Voltage: 200/100mA @ 12/24VDC 140/70mA @ 12/24VAC


Latch Status: SDPT, dry 3Amp @ 30V (standard)

**Keeper Closed and Deadlocked (standard)** 

Solenoid: Black, Red, Blue & Green

Keeper Open/Closed Status: SPDT, Dry 3Amp @ 30V


(optional)




**Monitoring:** 

## **Horizontal Adjustment**

Remove Faceplate. Loosen Horizontal Adjustment Screws and slide Die Cast Body out as needed. Retighten Adjustment Screws and replace Faceplate.



## HOLLOW METAL, SQUARE CORNER FACEPLATE



MATERIAL THICKNESS = .110

