





# 8000R RIM EXIT DEVICE-REVERSIBLE INSTALLATION INSTRUCTIONS

LHR door shown , RHR door opposite





Dogging: Depress push bar. Insert dogging wrench and turn 90°. The push bar will remain depressed and the latch will remain retracted.



# F8000R RIM FIRE RATED EXIT DEVICE-RERVERSIBLE INSTALLATION INSTRUCTIONS

LHR door shown , RHR door opposite



(A) door frame width minus 2-3/16" (56mm) (B)

